

1 Lay Out Grid



2 Level Bases



3 Nail Bases



7 Assemble Components

4 Measure Stanchions



5 Cut to Length



6 Apply Solvent Bond



Village of Alfred, NY
AccuPier Installation
50 ft. diameter x 24 ft. deep Bio-Tower

8 Place Grating on Piers